Document: How to configure your D-Link modem (DSL-320T, DSL-320B) with BeThere ISP.
Date: 6-Nov-08

How to configure BETHERE ISP line using modem (DSL-320T, DSL-320B) and router (DIR-635, DIR-655, DIR-855).

1) The modem needs to be configure in 1483 Bridged IP LLC mode with VPI: 0 and VCI: 101
(VCI and VPI are specific for BETHERE ISP)

2) Configure your router using Manual Internet Connection Settings

3) Next step depends on the type of connection provided by BeThere.
   You have to choices
   1) Static IP
   2) Dynamic IP

3a) Static IP
- Choose Static IP in Internet Connection Type
- Type in your connection details (IP address, Subnet mask, Default gateway, Primary DNS server, Secondary DNS server).

- Click Save Settings to apply.

3b) Dynamic IP
- Choose Dynamic IP in Internet Connection Type
- No more settings necessary

- Click Save Settings to apply.