How to access the USB SD Card media?

Step 1: Ensure your USB drive is properly connected to your DIR-850L

Step 2: Check USB driver/ SD card status from router's Web UI.
Step 2.1: Open your web browser and enter http://dlinkrouter or http://dlinkrouter.local or http://192.168.0.1 into the address bar.

Step 2.2: The default username is admin and the password is blank (nothing). Click Login.

Step 2.3 Click on the Setup tab at the top then click Storage on the left side

Step 2.4 Check the storage status

How to access the USB SD Card media?

D-Link®
Building Networks for People

**Step 3:** From a computer connected to the router:

Windows XP
1. Click **Start** then go to **Run**
2. Type \\ followed by the IP address of the router (default is 192.168.0.1)
   Example- \\192.168.0.1
3. Click OK

Windows 7
1. Click **Start** > **All Programs** > **Accessories** > **Run**
2. Type \\ followed by the IP address of the router (default is 192.168.0.1)
   Example- \\192.168.0.1
3. Click OK

How to access the USB SD Card media?

MAC OSX

1. Click **Go** > **Connect to Server**
2. Type smb:// followed by the IP address of the router (default is 192.168.0.1)
Example- smb://192.168.0.1
Click **Connect**

How to access the USB SD Card media?

Note: If prompted for password, select GUEST access