

D-Link[®]

xStack Storage[™]



D-Link xStack Storage iSCSI SAN Array

Managed SAN Solution

DSN-2100

Hardware Reference Guide

Version 1.0

© 2008 D-Link Networks, Inc. All Rights Reserved

D-Link Systems, Inc. makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. D-Link Systems, Inc. shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

This document contains proprietary information, which is protected by copyright. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of D-Link Systems, Inc.

The information is provided "as is" without warranty of any kind and is subject to change without notice. The only warranties for D-Link products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. D-Link shall not be liable for technical or editorial errors or omissions contained herein.

Copyright © 2008 D-Link Systems, Inc.™

Trademarks

Adobe® and Acrobat® are trademarks of Adobe Systems, Incorporated.

Java™ is a U.S. trademark of Sun Microsystems, Incorporated.

Microsoft Windows is a U.S. registered trademark of Microsoft Corporation.

Oracle® is a registered U.S. trademark of Oracle Corporation, Redwood City, California.

UNIX® is a registered trademark of The Open Group.

All other brand or product names are or may be trademarks or service marks, and are used to identify products or services, of their respective owners.

D-Link Systems, Inc.
17595 Mount Herrmann Street
Fountain Valley, CA 92708

Safety Information



There is a danger of a new battery exploding if it is incorrectly installed. Replace the battery pack only with the same or equivalent type recommended by the manufacturer. Do not dispose of the battery along with household waste. Contact your local waste disposal agency for the address of the nearest battery deposit site.

This product also uses a lithium coin cell battery. The lithium coin cell battery is a long-life battery, and it is very possible that you will never need to replace it. However, should you need to replace it, consult your service documentation. Do not dispose of the battery along with household waste. Contact your local waste disposal agency for the address of the nearest battery deposit site.

Following are the safety agency certifications that the xStack Storage enclosure has met:

CSA 60950-1

UL 60950-1

IEC 60950-1

EN 60950-1

Compliance Information

FCC Class A

CE Class A

C-Tick Class A

VCCI Class A

Notice of Export Controls

Export of technical data contained in this document may require an export license from the United States government. Please contact D-Link Systems, Inc. for any export compliance questions.

Document Revision Level

Revision	Date	Notes
Version 1.0	October 10, 2008	

Preface

This document is intended to assist users with installing the xStack Storage system from D-Link. This document assumes that users are computer literate, familiar with Storage Array Products, and have a basic understanding of storage products and concepts.

Typographic Conventions

Notes

Notes provide information that deserves special attention. They are preceded by:



Cautions

Cautions contain information which, if not followed, can cause damage to the xStack storage system. They are preceded by:



Warnings

Warnings contain information which, if not followed, can cause damage to the xStack storage system and to the person installing it. They are preceded by:



Related Documentation

In addition to this document, the following documents are available from D-Link.

- *xStack Storage Management Center Software User's Guide*. This guide provides the information needed to configure and manage storage on the xStack Storage system using the xStack graphical user interface.

Contact Information

You can find software updates and user documentation on the D-Link website.

D-Link provides free technical support for customers within the United States and within Canada for the duration of the warranty period on this product.

U.S. and Canadian customers can contact D-Link Technical Support through our website, or by phone.

Tech Support for customers within the United States:

D-Link Technical Support over the Telephone

Please see our support site for current number:

- <http://support.dlink.com>
- Monday to Friday 8:00am - 5:00pm PST/PDT

D-Link Technical Support over the Internet:

- <http://support.dlink.com>

Tech Support for customers within Canada:

D-Link Technical Support over the Telephone

Please see our support site for current number:

- <http://support.dlink.ca>
- Monday to Friday 7:30am to 9:00pm EST/EDT

D-Link Technical Support over the Internet:

- <http://support.dlink.ca>

Contents

Chapter 1	Introduction	9
1.1	Model	9
1.2	Benefits and Features	10
1.3	System Overview	10
Chapter 2	DSN-2100 Layout	11
2.1	Front Panel Components	12
2.2	Rear Panel Components	14
2.3	Side and Bottom Panel Components	16
Chapter 3	Installing the DSN-2100 Storage System	17
3.1	Site Considerations	18
3.1.1	General Considerations	18
3.1.2	Desktop, Floor or Shelf Installation	18
3.1.3	Rack-mount Guidelines	19
3.2	Unpacking the DSN-2100 Storage System	19
3.3	Items Supplied by the User	20
3.4	Connecting to the iSCSI Data Ports	21
3.4.1	Connecting to the DSN-2100 Host Network Connection Ports	21
3.5	Connecting to the Management Port	21
3.6	Connecting the Power Cords	22
3.7	Powering-on the DSN-2100 Storage System	22
Appendix A	Replacing and Upgrading FRUs	23
A.1	Installing the Battery Pack	23
A.2	Installing Memory	26
A.3	Installing or Replacing SATA Drives	28
A.4	Replacing a Fan	33
A.5	Replacing a Power Supply	35

This Page Left Intentionally Blank

Chapter 1 Introduction

The DSN-2100 storage system is an intelligent, high-performance multiple Gigabit Ethernet storage solution designed for small businesses that want to improve the reliability, availability, serviceability, and performance of their storage systems. It provides a range of benefits and features from its ability to use familiar, proven, and widespread networking technologies like IP and Ethernet for storage solutions.

Based on an Internet Protocol-Storage Area Network (IP-SAN) architecture, the DSN-2100 storage system is built around an iSNP8008 System-On-A-Chip, with the following features:

- Up to 8 internal Serial Advanced Technical Attachment (SATA) drives
- Up to 512 MB of system memory
- Up to 4 GB of buffer (cache) memory
- Four 1GbE local-area network (LAN) connectors accessed via the back panel
- A 10/100 Mbps management port
- An RS-232-C DB9 diagnostic port for troubleshooting purposes

Complete configuration and management are available through the intuitive, graphical-based xStack Storage Management Center.



For the latest information about supported drives, consult the Interoperability Matrix found on the D-Link Support Web site: support.dlink.com

1.1 Model

The DSN-2100 storage system is presently available as a single model.

Table 1-1. DSN-2100 Model Number

Model	Host Network Interface	Maximum Number of Internal SATA Drives
DSN-2100-10	Four 1GbE data ports	8

1.2 Benefits and Features

- High-performance, low-latency iSCSI storage system, with a highly integrated, reliable, multifunction ASIC for fully featured, integrated storage virtualization
- Modular design with expansion up to 8 SATA disk drives
- Easy setup and configuration - can be placed anywhere on a 10BaseT, 100BaseT, or Gigabit Ethernet network for improved access to critical information
- In-band or out-of-band management via a direct connection or the Web
- Delivers Ethernet economics to storage for lower total cost of ownership and rapid deployment using known and trusted technologies
- Proven transport infrastructure for increased reliability, investment protection, and reduced training costs
- Scalability over long distances - ideal for remote data replication and disaster recovery
- Three internal fans provide cooling
- Battery pack ensures that a charged battery is on hand to preserve buffer cache contents if a power failure occurs. Contents are backed up for approximately 72 hours.

1.3 System Overview

Figure 1-1 shows a typical DSN-2100 storage system configuration in a Storage Area Network (SAN). The SAN shown is an Ethernet network used solely for exchanging data between the customer's servers and the DSN-2100 storage system. The Ethernet bandwidth used by the servers exchanging data with the DSN-2100 storage system can be very high. Using a separate Ethernet to act as a SAN keeps that data from interfering with the customer's existing LAN and improves security.




Figure 1-1 DSN-2100 Storage System Diagram

Chapter 2 DSN-2100 Layout

This chapter describes the hardware components on the DSN-2100 storage system. The topics covered in this chapter are:


- Section 2.1, Front Panel Components
- Section 2.2, Rear Panel Components
- Section 2.3, Side and Bottom Panel Components

2.1 Front Panel Components

The front of the DSN-2100 storage system has the following components:

- Power LED - shows the DSN-2100 power on status. (see Figure 2-1 and Table 2-1)
- Boot and Fault LED - shows whether the DSN-2100 is ready for operation or encountered a fault condition. (see Figure 2-1 and Table 2-1)
- A lock on the bezel that protects access to the drives inside the unit.
- The hard drive power and drive activity/fault LEDs. (see Figure 2-1 and Table 2-2)

Bezel:



Drive Bays:




Figure 2-1 Front View of the DSN-2100 Storage System



When installed, the front bezel uses pipes to pass light from the LEDs behind it to the front for viewing. The bezel itself is passive and has no active LEDs.

Table 2-1. Front Panel LEDs

LED	Color	Description
Power	Green	ON = DSN-2100 is powered on.
		OFF = power is not being received.
Boot and Fault	OFF	Array is powered off or performing its Power On Self Test.
	Red	ON = a fault has occurred.
	Green	ON = normal operation.

Table 2-2. Hard Drive LEDs (for each drive 0 through 7)

LED	Color	Description
Drive Power	Blue ON	Drive is powered and operational.
Drive Activity and Fault	Green Blinking	Data being transmitted or received from corresponding SATA drive.
	Red ON	Drive has experienced a fault and is offline

2.1.1 Front Vents

The enclosure that houses the xStack Storage Array contains a set of three hot-swappable fans located in the mid-section of the chassis drawing air into vents in the front of the unit, cooling the hard drive array and other components. This air exits the chassis through a grill located at the rear of the chassis. It is advised that the unit only be operated with the top cover in place. When installing the xStack Storage Array, please be sure these vents are not blocked.



A fully loaded array with all drive bays filled can generate a significant amount of heat. Please be sure the cover is in place to provide the forced air flow required for proper cooling.

2.2 Rear Panel Components

The rear of the DSN-2100 storage system enclosure has the following components:

- Four 1 GbE RJ-45 iSCSI host network data ports. Each iSCSI data port has port speed and port activity LEDs. (see Figure 2-2, Figure 2-3 and Table 2-4)
- Diagnostic port (**Diagnostic Port**) - one 9600 bps RS-232-C DB9 diagnostic port is located to the right of the iSCSI data ports. This requires a female-to-female straight-through cable provided with the system. (see Figure 2-2 and Figure 2-3)
- Management port (**Mgmt 10/100**) - one 10/100 RJ-45 management is located to the right of the diagnostic port. The management port has port speed and port activity LEDs. (see Figure 2-2, Figure 2-3 and Table 2-5)
- Power switch and reset switch - are located to the left of the power supply (see Figure 2-2, Figure 2-4 and Table 2-3).
- Power - two power receptacles are located on the right side of the rear panel.
- Power supply alarm silence button - located on the rear of the power supply. (see Figure 2-2)




Figure 2-2 Back View of the DSN-2100 Storage System




Figure 2-3 Close-Up View of the DSN-2100 Rear Panel




Figure 2-4 Power and Reset Switches

Table 2-3 Rear Panel Switches

Switch	Description
Power	Applies power to the DSN-2100 storage system. Pressing this switch for longer than 3 seconds removes power from the DSN-2100 storage system and turns it off.
Reset	Resets the DSN-2100 storage system.

Table 2-4. Data Port Speed and Port Activity LEDs


	LED	Color	Description
	Port Speed	Yellow	ON = link is operating at 1 Gbps.
			OFF = link is operating at either 10 Mbps or 100 Mbps.
	Port Activity	Green	ON = link is operational.
Blink = data is being sent or received.			

Table 2-5. RJ-45 Port Activity LEDs for the Fast Ethernet Management Port

Color	Description
Green ON	Link is operational.
Green Blinking	Data is being transmitted or received on the RJ-45 port.
Yellow OFF	Connection has been established at 10 Mbps.
Yellow ON	Connection has been established at 100 Mbps.

2.3 Side and Bottom Panel Components

The left and right sides of the DSN-2100 storage system enclosure has rails for rack-mounting the unit. Product information labels will be found on the side, bottom, or back of the unit. For rack-mount instructions, refer to the documentation for the rack.

Chapter 3 Installing the DSN-2100 Storage System

This chapter describes how to install the DSN-2100 storage system. The topics covered in this chapter are:

- Section 3.1, Site Considerations
- Section 3.2, Unpacking the DSN-2100 Storage System
- Section 3.3, Items Supplied by the User
- Section 3.4, Connecting to the iSCSI Data Ports
- Section 3.5, Connecting to the Management Port
- Section 3.6, Connecting the Power Cords
- Section 3.7, Powering-on the DSN-2100 Storage System

3.1 Site Considerations

The site where you install the DSN-2100 storage system can affect its performance. Therefore, choose a site that conforms to the requirements in the following sections.

3.1.1 General Considerations

Observe the following considerations when selecting a location to install the DSN-2100 storage system.

- The location should be fairly cool and dry for the acceptable temperature and humidity ranges.
- The location should be free of strong electromagnetic field generators (such as motors), vibration, dust, and direct exposure to sunlight.
- The location must provide sufficient airflow to the front and back of the DSN-2100 storage system for correct cooling. Ventilation must be sufficient to exhaust heat from the rear of the equipment.
- The location should offer a power outlet within six feet (1.82 meters) of the DSN-2100 storage system.
- The location should allow for at least six inches (152.3 mm) of space at the front and back of the DSN-2100 storage system for ventilation.
- Do not place the DSN-2100 storage system next to, on top of, or below any device that generates a significant amount of heat or will block the free flow of air through the DSN-2100 ventilation slots.

3.1.2 Desktop, Floor or Shelf Installation

The DSN-2100 storage system can be mounted on a desktop or shelf. Observe the following considerations for desktop or shelf installations.

- Select a sturdy, level surface that can support the DSN-2100 storage system. A fully populated unit weighs approximately 45 lbs. (20.4 kg.).
- Allow enough ventilation space between the DSN-2100 storage system and any other objects in the vicinity.
- Be sure not to block the air vents on the front and back of the DSN-2100 storage system enclosure. Install the cables and power cords according to the procedures in the following sections.

3.1.3 Rack-mount Guidelines

The DSN-2100 storage system can be mounted in a standard 19-inch rack. Observe the following considerations for rack installations. For information about installing the system in a rack, refer to the documentation for the rack.

- All rack-mounting hardware must be carefully assembled to properly support the equipment. Follow the instructions in the documentation for the rack.
- The operating ambient temperature of rack-mounted equipment must not exceed the maximum rated ambient temperature indicated in this guide.
- The rack cabinet must provide sufficient airflow to the front and back of the DSN-2100 storage system to maintain correct cooling. It must include ventilation sufficient to exhaust the heat generated by equipment installed in the rack.
- The rack must allow enough ventilation space between the DSN-2100 storage system and any other objects in the vicinity. Do not block the air vents on the front and back of the DSN-2100 enclosure. The air flow clearances specified in this guide must be maintained within the rack.
- The AC supply circuit for rack-mounted equipment must be capable of supplying the total current specified on all the labels of the rack-mounted equipment.
- All AC power supply connections must be properly grounded. To ensure the integrity of the earth connection, special attention must be given to connections that are not directly connected to the branch circuit (for example, power strips).

3.2 Unpacking the DSN-2100 Storage System

After receiving the DSN-2100 storage system, perform the following steps to ensure that it and other contents arrived safely.

1. Inspect the outer shipping container for any damage that may have occurred in shipping. Report any sign of damage to the appropriate shipping agency.
2. Remove the DSN-2100 storage system and cables from the shipping container.
3. Save the shipping container, foam, and antistatic bags in case you have to return the DSN-2100 storage system. Returning the DSN-2100 storage system in any other container is not advised.
4. Check the contents against the items referenced on the packing list. If any item is missing or damaged, notify a sales representative and/or the shipping agency.

3.3 Items Supplied by the User

Table 3-1 lists the additional items you must supply to perform the DSN-2100 storage system installation. All users must provide the items in the first row of Table 3-1. Thereafter, the additional items required for installation depend on the user category into which you fit.

Table 3-1. User-Supplied Items to Perform the DSN-2100 Storage System Installation

User Category	User-Supplied Items
All Users	<ul style="list-style-type: none">▪ A PC with a Network Interface Card (NIC) that will act as the iSCSI initiator. (See Note 1.)▪ A PC with a NIC and Internet access that will access the management console. (See Note 1.)▪ One or more available AC outlets not controlled by a wall switch.▪ <i>Optional:</i> An Ethernet switch and Ethernet cable. If you want to use the DSN-2100 storage system's Link Aggregation feature, the switch must support LAGs.▪ An IP address for each DSN-2100 storage system host connection RJ-45 data port that will connect to your SAN.▪ An Ethernet cable for each DSN-2100 storage system host connection RJ-45 data port that will connect to your SAN (the DSN-2100 storage system auto-senses the cable type used).
Rack-Mount Users	<ul style="list-style-type: none">▪ A standard NEMA-compliant 19-inch rack.▪ Additional Mounting hardware for specific rack being used.
Note 1: For convenience, one PC with three installed NICs can be used instead of separate PCs. In this configuration, one NIC connects to the DSN-2100 storage system management port, a second NIC connects to the Internet, and a third NIC is used with the iSCSI initiator.	

3.4 Connecting to the iSCSI Data Ports

The following sections describe how to connect the DSN-2100 data ports.

3.4.1 Connecting to the DSN-2100 Host Network Connection Ports

The DSN-2100 storage system has four RJ-45 data ports. These ports connect to your SAN using either a straight-through or cross-over RJ-45 Ethernet cable (the DSN-2100 storage system auto-senses the type of cable used). One cable is needed for each RJ-45 data port.

1. Attach one end of an Ethernet cable to host network connection port 0 on the DSN-2100 storage system back panel. Connect the other end of the cable to your SAN or host system.
2. To connect additional host network connection ports to your SAN, repeat step 1 using another Ethernet cable and the next available DSN-2100 storage system port in sequence (port 1, then port 2, and so on). Do not skip ports when making these connections.

3.5 Connecting to the Management Port

Connecting a PC to the management port lets you configure and manage the DSN-2100 storage system. This connection is made using a PC with an installed NIC and either a cross-over cable (if connecting directly to the management port) or a straight-through cable (if connecting to the management port using a hub or switch).

To receive email alerts from the DSN-2100 storage system, be sure the management port can communicate via Ethernet with your mail server.

1. Connect either end of an Ethernet cable to a NIC installed in a PC.
2. Connect the other end of the cable into the DSN-2100 storage system **Mgmt 10/100** port. This port is located to the right of the diagnostic port on the back panel (see Figure 2-3).



Do not connect one NIC to the management and host network connection ports. Connect one NIC to the management port and connect another NIC in the same PC or a different PC to the host network connection port(s).

3.6 Connecting the Power Cords

The DSN-2100 storage system has a two power receptacles. Both must be used to connect the DSN-2100 to an AC outlet:

1. Plug the female end of the power cord into the 3-pronged power connectors on the back of the DSN-2100 storage system. Plug the other end of the power cord into a working AC outlet that is not controlled by a wall switch.
2. Repeat the previous step using the second power cable and power receptacle on the DSN-2100 storage system. For best results, all both power receptacles should be on a different circuit.



Although the DSN-2100 storage system can operate temporarily with only two AC power connections, an audio alarm will sound until both power receptacles are used.

3.7 Powering-on the DSN-2100 Storage System

To power-on the DSN-2100 storage system, press the power switch on the back panel. When the DSN-2100 storage system powers-on, the following actions occur:

- The DSN-2100 storage system Power LED turns green (see Figure 2-1).
- The DSN-2100 storage system runs its power-on procedure (~4 minutes), then the Ready/Fault LED turns green and drive LEDs may flash.

The completion of the power-on process can be verified as indicated in Table 3-2.

Table 3-2. Verifying Completion of the DSN-2100 Storage System Power-on Process

If the DSN-2100 Storage System...	Verify the Power-on Process by...
Has no front panel Ready/Fault LED	Wait five minutes after powering-on the DSN-2100 storage system.
Has a front panel Ready/Fault LED.	The LED turns green when the startup process completes. If the LED turns red, reboot the DSN-2100 storage system. If the problem persists, contact Technical Support.
Diagnostic port is connected to a PC via a diagnostic cable.	The message RCP sequence complete appears on the PC monitor. After verifying this message, disconnect the PC from the diagnostic port.

After the DSN-2100 storage system powers-on for the first time, it automatically loads the factory-default configuration settings. If necessary, you can use the xStack Storage Management Center to change these settings to suit your requirements. For a description of the array's factory-default configuration settings and how to change them, refer to the xStack Storage Management Center User's Guide.

Appendix A Replacing and Upgrading FRUs

This appendix describes how to replace or upgrade the Field Replaceable Units (FRUs) in your xStack Storage Array. FRUs that can be replaced or upgraded include:

- Battery Pack
- System and buffer memory
- SATA drives
- Fans
- Power supplies

A.1 Installing the Battery Pack

The xStack Storage Array accommodates a 4-cell or 6-cell shrink-wrapped battery pack. Because write-back caching is always enabled, we recommend you have a battery to back up the buffer cache contents.

To install a battery in your xStack Storage SAN Array, follow these steps:

1. Hold the battery as shown to align the fastener pad. Make sure the battery cable and connector is located nearest to the battery socket J35 on the controller (see Figure A-1).



Figure A-1 Aligning the Battery

2. Press the battery down firmly as shown in Figure A-2 until you feel it lock into place.



Figure A-2 Press the Battery Down Firmly Until it Locks

3. Align the battery plug with connector J35 as shown in Figure A-3 and insert it fully into the socket.




Figure A-3 Align the Battery Plug with Connector J35

4. The connector locked firmly into connector J35.




Figure A-4 Battery Plug Locked in Place

5. The installed battery is shown in Figure A-5.



Figure A-5 The Installed Battery

A.2 Installing Memory

The xStack Storage Array provides four memory sockets:

- Two sockets (**J36** and **J37**) are for buffer/cache memory
- Two sockets (**J38** and **J39**) are for system memory

System Memory: The xStack Storage controller can address up to 2GB of system memory, but only 512MB are required for operation of your controller. Your controller will have come standard with at least 512MB (2 x 256MB modules) making upgrading of system memory not necessary. Please see Figure A-6 system memory location.

Buffer (Cache) Memory: The xStack Storage controller can address up to 2GB of buffer memory, and comes standard with at least 512MB (2 x 256MB modules) installed. This should work well for most applications. However, several applications (such as video streaming) of the product could benefit from increased cache memory. Please see Figure A-6 for buffer memory location. **Note on Memory:** The xStack Storage controller's system and buffer memory must be installed as matching pairs. Table A-1 lists the specifications for DIMMs supported by the xStack Storage Array. These memory module specifications are crucial to the operation of your SAN array. Please visit the www.dlink.com website for tested memory modules.

Table A-2 shows the possible memory configurations for your xStack Storage controller. Please note that you must use matching memory modules for DIMM0 & DIMM1 as well as matching memory modules for DIMM2 & DIMM3.




Figure A-6 Buffer and System Memory Location

Table A-1. xStack Storage Array DIMM Specifications

Requirement	Description
PC2700/DDR333 speed	SDRAMs must be JEDEC compliant and DDR333 capable, with a CAS latency of 2.5. PC2100/DDR400 speed DIMMs can be used if they support a 2.5 CAS latency when operating at DDR333 speed.
ECC	DIMMs must be organized as x72 bits wide, allowing support for ECC.
X8 RAMs	DIMMs must use 8-bit wide DRAMs that can support data mask (DM) signals. DIMMs that use 4-bit-wide DRAMs do not provide DM signals and cannot be used.
Registered	DIMMs must be registered as per the JEDEC specification for registered DIMMs.
Buffered	DIMMs must be buffered as per the JEDEC specification for buffered DIMMs.
Organization	Conforming DIMM organizations are shown in Table A-2..

Table A-2. DIMM Organization

DIMM 0 (J38) System Memory Module	DIMM 1 (J39) System Memory Module	Total System Memory	DIMM 2 (J36) Buffer/Cache Memory Module	DIMM 3 (J37) Buffer/Cache Memory Module	Total Buffer/Cache Memory	Total Memory
256MB	256MB	512MB	256MB	256MB	512MB	1GB
256MB	256MB	512MB	512MB	512MB	1GB	1.5GB
256MB	256MB	512MB	1GB	1GB	2GB	2.5GB
256MB	256MB	512MB	2GB	2GB	4GB	4.5GB

A.3 Installing or Replacing SATA Drives



Removal of a populated drive/tray assembly can have unforeseen effects including the loss of all data in a volume. A drive can be part of a volume that may or may not be redundant. Before removing a drive from an operating xStack Storage Array, make sure it is the correct one.

A.3.1 Drive and Tray Removal

A drive/tray assembly can be removed by pressing upwards on the green latch found on the tray and removing it with the handle as shown in Figure A-7 and Figure A-8.




Figure A-7 Drive and Tray Removal




Figure A-8 Remove Drive/Tray

A.3.2 Installing a Hard Drive in a Drive Tray

Follow these steps to install a hard drive in a drive tray.

1. Remove the plastic air dam from the tray by squeezing the two levers together and lifting the piece out of the tray as shown in Figure A-9.




Figure A-9 Removing the Plastic Air Dam Piece

2. Your tray should now look like Figure A-10.




Figure A-10 Tray with Air Dam Removed

3. Place new hard drive in tray as shown in Figure A-11.



Figure A-11 Place Hard Drive in Tray

4. Align the mounting holes and insert four mounting screws to hold the drive securely in the drive tray as shown in Figure A-12.




Figure A-12 Secure the Hard Drive in the Drive Tray

5. Your hard drive is ready for installation. Proceed to A.3.3.



A.3.3 Drive and Tray Installation

A drive/tray assembly can be installed by inserting the drive/tray assembly into the open drive bay as shown in Figure A-13. Push the tray at the point indicated in Step 2 of Figure A-14 and push until it is seated firmly within the bay. As you press, you will see the tray handle begin to move inwards as the locking mechanism enters the locking slot. When you see this, then you must push the tray handle inwards as shown in Figure A-15 until you hear the green locking mechanism click.




Figure A-13 Drive/Tray Installation



Figure A-14 Press Here Until You See the Lever Move Inwards




Figure A-15 Press Lever Inwards Until it Locks

A.4 Replacing a Fan

The xStack Storage Array contains three user replaceable fans. They can be replaced as follows.

1. Locate the failed fan. They can be identified by their green handle as seen in Figure A-16.




Figure A-16 A User Replaceable Fan with Green Handle

2. Lift the handle, grasp it and pull the fan upwards as seen in Figure A-17.



Figure A-17 Lift the Handle and Pull Upwards

3. Remove the fan from its socket as seen in Figure A-18.




Figure A-18 Remove the Fan

4. Insert the new fan by reversing the previous steps. i.e. Insert fan into socket, press firmly downwards until it is seated and lower the handle to lock it in place.

A.5 Replacing a Power Supply

The xStack Storage Array contains three user replaceable power supply modules. They can be replaced as follows.

1. Locate the failed power supply module. Unscrew the bolt holding the locking mechanism in place as shown in Figure A-19.




Figure A-19 Unscrew the Bolt Holding the Locking Mechanism

2. Push the locking lever to the left and pull on the handle as shown in Figure A-20.




Figure A-20 Push the Locking Lever to the Left and Pull Handle

3. Remove the power supply module as shown in Figure A-21.



Figure A-21 Remove the Power Supply Module

4. Insert the new power supply module by reversing the previous steps. i.e. Insert the new power supply module into the bay until it seats against the rear and the lever locks. Then screw the locking bolt into place.